

INSTRUCTIONS



Insert

AC-FIX PRESS COMPACT 2 (91.10322.01/02)

This tool should be sent to the technical service at least once a year from the date of purchase for review and maintenance. Ask your supplier about the technical service.



Press the pin to replace the insert. When you replace the insert, the battery of the tool must be released in order to avoid any accident.



Be sure that the gap between the inserts is less than 0,2mm when the tool stops.



The jaw can be turned 90 degrees.



Put the fitting into the right insert.



Ex-factory setting value is 50



When the gap between the inserts is more than 0,2mm, turn the screw clockwise as shown in the picture (max. value can't be more than 53).



When the green light flashes, it means it is charging; when the two lights are on, it means it has finished charging.